

Processing information

PUREFLEX roll and board

Unroll material

- Release and remove the plastic tape and packing material
- If necessary create an auxiliary construction

Cut material from roll

- Cutter
- Carpet knife
- Eventually with thermal cutter (<140°C)
- Electric reciprocating saw and insulation blade with serrated edge

Cut material on-site

- Cutter
- Carpet knife
- Eventually with thermal cutter (<140°C)
- Electric reciprocating saw and insulation blade with serrated edge

Cleaning of site and equipment

- Vacuum with industrial vacuum cleaner equipped with a fine dust filter
- Clean surfaces with soapy water

Disposal, recycling

- Thermal disposal (KVA)